



armus
N A N O T E C H N O L O G Y

SMART, SUSTAINABLE
NANO-FORMULATED SOLUTIONS

WOOD GUARD

APPLICATION GUIDE

SURFACE PREP, APPLICATION & CARE GUIDE

REQUIRED TOOLS

MICROFIBER CLOTHS

LOW PRESSURE PUMP SPRAY & FAN TIPS

We recommend using a low-pressure (<50 psi) pump-type spray equipment. This can be an electric sprayer, hand pump or backpack sprayer. Fan tips are recommended for an even spray and even coverage over the substrate.

PAINT BRUSH OR PAINT ROLLER (OPTIONAL)

Brushes / paint rollers should be used on small-scale applications. Foam or synthetic brushes and rollers can be used with Wood Guard.



SURFACE PREP

1. Wear protective gloves & gear before applying.
2. Protect vehicles, and surrounding surfaces not set for treatment.
3. Thoroughly clean surface. We recommend using a wet mop and following with a high-pressure vacuum to remove dust, dirt and debris.
4. Ensure surface is completely dry.

APPLICATION INSTRUCTIONS

DO NOT DILUTE PRODUCT. SHAKE CONTAINER WELL BEFORE USE. LOAD PUMP SPRAYER OR PAINT TRAY AFTER MIXING WELL.

VERTICAL APPLICATIONS

SPRAY: Saturate from bottom up. Apply enough for a 4-8in rundown below the spray contact point. Let first coat penetrate for 5-10 min before applying second coat.

BRUSH / ROLLER: Only for small scale applications. Apply uniformly and saturate the surface. Let product penetrate for 5-10 min. Brush out heavy runs and drips that do not penetrate.

HORIZONTAL APPLICATIONS

We recommend applying to horizontal surfaces using a sprayer. Apply in a single-saturating coat. Do not over-apply. Back roll out any puddles thoroughly until they penetrate the surface. Wipe up any excess material with a microfiber cloth.

APPLICATION CONDITIONS

Surface and air temperatures must be at least 50°F (10°C) during application and for 8 hours following and should not exceed 95°F (35°C). Do not apply by sprayer in windy conditions to prevent loss.